

# CXM

## Remote Display for Phocos CXN Charge Controller



- Display for panel current, load current, and battery voltage, Ah, SOC, etc
- Clear, readable 3-digit LCD Display and symbols
- Two push button to select displayed value
- Prepared for DIN rail and wall mounting

Phocos' CXM can be used in combination with Phocos CXN series charge controllers via interface connector.

Phocos' CXM remote display is designed to display panel current, load current and battery voltage of your PV system as true values and status values like charging, overload, low voltage disconnect as symbols. Additionally you can display several values of CXN's data logger of the past 7 days as Ah, SOC, Battery voltage (morning, evening).

This provides you more detailed information of your PV system.

TYPE	CXM
Voltage Range	Display voltage range of your CXN
Current Range	Display current range of your CXN
Operating Temperature Range	-25 to +50 °C
Length of Connecting Wire	2m
Dimension	72 x 68 x 29mm
Weight	94gr (with connecting wire)
Type of Protection	IP22

Phocos AG, Germany  
info@phocos.com

Phocos China Ltd., China  
Info-china@phocos.com

Phocos India Solar Pvt. Ltd., India  
Info-india@phocos.com

Phocos Latin America S.R.L., Bolivia  
Info-latinamerica@phocos.com

Phocos Rep. Office Australia, Australia  
Info-australia@phocos.com

Phocos Rep. Office Brazil, Brazil  
Info-brazil@phocos.com

Phocos Rep. Office Eastern Africa, Kenya  
Info-easternafrica@phocos.com

Phocos Eastern Europe S.R.L., Romania  
Info-easterneurope@phocos.com

Phocos SEA Pte Ltd, Singapore  
Info-sea@phocos.com

Phocos Rep. Office South Africa  
Info-sadc@phocos.com

Phocos Tunisia  
Info-maghreb@phocos.com

Phocos USA  
Info-usa@phocos.com